


**ΨAΘIN®**

**Owner's Manual**


**MC-10L**

***TUBE AMPLIFIER***

# MC-10L



- ① Volume: Min-Max
- ② Power: On/Off
- ③ Selector: Tape, DVD, CD, Tuner



- ④ Audio Input Jack
- ⑤ Speaker Jack
- ⑥ Power Plug

**Technology Vacuum Tube Amplifier**

**Specification:MC-10L**

**Out Power:52W**

**Output Impedance:4 Ohm,8 Ohm**

**Frequency Response:20Hz-60KHz**

**Distortion:2%**

**Input Impedance:20K Ohm**

**Input Sensitivity:300mV**

**S/N Ratio:85dB**

**Fuse:F2AL250V**

**Vacuum Tube:6N1×4,EL34B×4**

**Dimension:460×314×175mm**

**Weight:16.9kgs**

## **Troubleshooting**

**Symptom:No power**

**Make sure the power cord is conneted properly and the power is on**

**Symptom:No sound**

**Check the audio connection(s) and the power is on**

**Sympton:No sound (Right Speaker)**

**Check the audio connection(s) and the signal cord**

**Sympton:No sound(Left Speaker)**

**Check the audio connection(s) and the signal cord**

**Sympton;Sound and image position incorrect**

**Check the[+] [-] of the specker is inversely connected and whether the non-original audio-video product is plaued**

**Sympton:Noise**

**Check the input signal connection**

**Check the connection between the tube and the tube socket**

**Make sure no non-shielded or poor shielded signal cord is used**

**Make sure no electric generator or motor is working and interfering nearby**